When Turning on your PC
For 64 bit PC
Windows 7
Please press F8 key to enter into Advanced Boot Options menu to choose Disable Driver Signature Enforcementbefore Windows starts loading
Windows 8 or 10
Please follow the instruction of this video to Disable Driver Signature Enforcement
https://www.youtube.com/watch?v=71YAIw7_-kg

For 32 bit PC
Just turn it on normally

1. Download the Firmware Reflash File
http://www.runcam.com/download/Reflash_V2.2.zip
and unzip it, you will get these

2. Install SPCA_Driver_v1001.EXE driver by choosing “install this driver software anyway”

3. Remove the battery of RunCam 2, hold the WiFi button to connect the camera to your PC through a USB 2.0 port. (NOTE: USB 3.0 not supported). There will be two new devices recognized under Computer Management.

4. Enter into download file, follow up...

FRM[2.8.5.49] [MP Mode]
Basic
Advanced
spca6350 [User : spca6350isp.bin]
Option
Program All
F/W + Partial RSV
F/W Only
RSV Only
Read Verify
Auto Power Off
Backup/Restore RSV
FlashType
SPI
Customize
NONE
GPIO_GRP_TGL
TGGPIO1
ISP(F5)
USB(F6)
Working Folder : C:\Users\Administrator\Desktop\Reflash_V1.3.0\downloa
Firmware : SPC.BIN
Settings : EVB_DDR3_1G_MDP_2-300MHz.prm
SPI

FRM [2.8.5.49] - ISP [6350.0030]
Basic
Advanced
spca6350 [User : spca6350isp.bin]
Option
Program All
F/W + Partial RSV
FlashType
SPI
Customize
FRM
More disk space(1152KB) is needed.
Select YES to realloc the size of AIMG on platform!
Yes
No
Working
Firmware
Settings : EVB_DDR3_1G_MDP_2-300MHz.prm
SPI
1152KB is needed by AIMG!

5. Done

Unplug the camera, replug the battery and turn it on. It works (again)!